

Instruction manual for AQHM

Dear users,

Please read the manual before installing and using.

Specification: Showing on the package

The functional instruction:

Massage, foot massage, radio, telephone, seven-colored light, ventilated fan

Steam is available (with a piece of computer controller manual)

The install use request:

Water pressure: 0.1~0.5Mpa

1. If water pressure is too low, propose to install the miniature pressurization device. When the water pressure > 0.5Mpa, Please install relieving press valve. the filter should be installed in the place where water quality is bad, The hot water temperature Should be 60~80c.
2. The power of 220V, 50HZ are recommended.
3. The design of the drainage should be rational, to guarantee to drain off.
4. If with the steam engine, Join the earth connection on the steam engine to the earth connection on the building Safely.
5. Please don not install the shower room outdoors or bad environment.

Remarks: the picture maybe does not correspond to material object, however, It does not influence the installing and using.

If change, does not notify especially.

The installing preparation

Please check carefully, if find the lackage of the fittings, please contact the supplier

Fittings check:

- There are three packages together:
1. The package of the enclosure
 2. The package of the backboard
 3. The package of the top and tray

The package of the enclosure:

movable door	2PC	
fixed door	2PC	
Magnetic strip	1PC	Used for movable door
Long of hold up water strip	2PC	Used for movable door
sholt of hold up water strip	2PC	Used for fixed door

Fitting list:

Doorknob	2pc	
Distance piece	8Pc	To fix the pulleys
4*10round screw	8Pc	used for distance piece
Plastic piece	4Pc	fixation fixed door
4*16butch haircut screw	4Pc	used for plastic piece
4*16round screw	8Pc	joint track and side column D
4*10compressed screw	6Pc	joint backboard and side column
4*10compressed screw	6Pc	joint backboard and tip and tray

2. The package of the backboard: backboard 1pc


3. The package of the top and tray:


Top cover	1pc	
tray	1pc	
track	2pc	To fix the glass door
shower rose	1pc	
Double-locked hoes	1pc	To connect the shower rose
Cold-hot water pipe	1pc	

Installing instruction


Square one: Assemble the building

1. used for 4*40round screw joint track and side column.






2. used for 4*16 butch haircut screw fixation Plastic piece.
3. fix sholt of hold up water strip in to fixed door.
4. move the door vertically, let the pulley slip into the track.
Remarks: let the top pulleys slip into the track first, then slope the middle door to make the low pulleys slip into the tracks.
5. Fix doorknob.
6. Fix Long of hold up water strip in to movable door.
7. Fix Magnetic strip.
8. Used for 4*10 round screw maintain Distance piece onto track.




The second: The whole assemblies

1. Up the enclosure with at the top of the tray.
2. Up the backboard with at the top of the tray.
3. Preset a station oven.

4. used for 4*10 compressed screw fixation backboard and enclosure.



5. used for 4*10 compressed screw fixation backboard and tray .



Trouble classifications	Reasons	Checking steps
All functions cant be started	The power is obstructed	<ol style="list-style-type: none"> 1. check the power. 2. four connections become flexible. 3. the circuit board burns out.
The light is not shiny	<ol style="list-style-type: none"> 1. the button is bad. 2. the light is out of order. 3. it is loose to connect 	<ol style="list-style-type: none"> 1. the indicator lamp is bright then the electric apparatus burns out 2. the indicator lamp is not bright, check the connections.
The fan does not work	<ol style="list-style-type: none"> 1. the key is out of work 2. the fan is out of order 3. it is loose to connect 4. it is reverse to connect 	<ol style="list-style-type: none"> 1. indicator lamp is bright, 8050 is burn out 2. the indicator lamp is not bright, check the reason
It is few in radio reception that the radio has noises	<ol style="list-style-type: none"> 1. The aerial unblocking 2. The direction of the aerial is not straight 3. The radio reception signal is weak 	<ol style="list-style-type: none"> 1. Regulate the aerial 2. When the signal is weak in some areas, You should draw the aerial to the spacious or proper position outdoors
The radio has no sound	<ol style="list-style-type: none"> 1. The radio is out of order 2. It is loose to connect 	<ol style="list-style-type: none"> 1. Check the radio line piecing 2. Check whether have already adjusted it to supreme frequency, to low frequency by pressing the REST , search again.
The telephone can't be answered	<ol style="list-style-type: none"> 1. The telephone wire has not been put through 2. There is no signal 3. The circuil is bad 	<ol style="list-style-type: none"> 1. Check the telephone wire 2. Check the signal 3. Check the controller

Using instruction

Operating instruction:

1. Open the water source , cold and hot water temperature should be adjusted by the roundness wrench ,be sure that make it best .
2. Adjust the water separator to appropriate ,and customer can enjoy different style of shower
3. Foot massage use instruction put the foot massage on the shower tray , put your feet on it ,then move the feet forward and backward.
4. water in cabinet should be not more than 70centigrade ,donnot power the boiling water into showercabinet ,in case that causing some damage.

Clean and maintenance:

1. Use liquid scour and soft cloth to clean the surface ,please do not use acet mmonia,organic solvent .And do not use formaldehyde relevant products to sanitize otherwise the surface will be damaged.
2. If the surface was scratched or scortched ,please use 1500# sand paper, plus, toothpaste .then polish them with soft cloth.
3. Use polishing preparation to polish to remain the surface flashing .
4. It is not necessary to polish the chromate treatment parts frequently (Prevent to contact the organic solvent, chemicals)
Attention:the glass glue with acid will damage the surface of the electrolate parts.
5. please don not polish the surface with rough utensil, or chemical solution. Please do not cave or knock the surface of the shower room with knife or blunt utensil.
6. Check the power wire, draining ,providing pipe frequently, avoiding to cause losses.

Attention: transportation and stock

1. do not place it upside down in stock, it is not permitted place with formic acid and formaldehyde together
2. Please take it lightly in carrying, prevent heavy press, knock and strong vibration.
3. keep the surroundings dry, ventilate, turn off the water source and power when out of using.

Ordinary malfunction

Phenomena	Failure source	Treatment method
No power	Power socket has bad connection	Check the socket
	Poor power connection	Check the power connection, turn on the power
No spray	Water pressure abnormality	Check the water pressure
	Water separator unconnected or walled up	Connect it or mend it
	Bulb was broken	Change or clear up the water pipe
Parts go moldy	Chemical causticity pollute it	Do not touch with causticity substance
	Stiffness, humidity	Improve the ventilation situation
No light	Light wire has bad connection	Check the socket
	Bulb was broken	Instead of the bad one
	No voltage	Instead of the bad one
Exhaust fan cannot run	Lead was bad connection or connect way is wrong	Check the circuit ,and pillar
	Exhaust fan circuit was damage	Instead of old one
	No voltage	Instead of the power box
Radio is unclear	Signal is weak or disturbance	Remove the disturbance and ajust the location of the antenna
	Installation is not correct	Regulate again
Wrong work of glass door	The frame of door is not vertical	Make the frame be vertical
	Friction is great	Add some lubricant into track and frame